fishman.com/fluence

**FISHMAN** *FLUENCE*™

**Voice Select (GRAY)**
Voice 1: selected if wire is not grounded.
Voice 2: selected if connected to ground.

**High Frequency Tilt (BLUE)**
To activate, connect to ground.

**Preamp Output (ORANGE)**
Connect to Volume pot.

**Ground (BLACK)**
Connect to pot & bridge ground.

**Battery + (RED)**
Connect to battery positive terminal.

**Coil output (WHITE)**
Connect to 5-way switch.

**Preamp input (YELLOW)**
Connect to 5-way switch pole.

For best performance, insulate any wire that is not used.