FISHMAN FLUENCE^T Mick Thomson Humbucker Set 9V Battery Volume - Pull for Voice-3 Outer Coils (Inner Coils Default) Mini Toggle for Voice Select Voice-1 Bass Boost ППП пппп (-) Connect to Ground (+) to activate or apply Output Λ Δ jumper across the Ring Jack two pins. Bridge Pickup Neck Pickup Sleeve SHM FLUENC ICE LUE on Bridge Thomson Neck Tip Bridge Ground • • 2 Voice 0 **A** • • Select \circ DPDT Э \cap 3 0 0 ON-ON-ON 25k (a.k.a. SP3T) Mini Toggle Bridge Neck Volume Example: NKK Pickup Selector "Import" Style Toggle M2024SS1W01 Pull for

Outer Coils when

Voice-3 Selected (Inner Coils Default)

GND