


# FISHMAN FLUENCE™

## Tim Henson Humbucker Set

Volume

Tone - Pull for Voice-2 (1,3,& 5 positions)

Schaller Megaswitch-M 5-way Switch



### Switch Positions:

1. Bridge Humbucker (Voice-1 or 2 selectable)
2. Bridge & Neck - Neck side Coils (Bridge Voice-3)
3. Bridge & Neck Humbucker (Voice-1 or 2 selectable)
4. Neck - Neck Side Coil (Voice-3)
5. Neck Humbucker (Voice-1 or 2 selectable)