

# **FISHMAN®**


---

## **USER GUIDE FT-5 CLIP-ON TUNER**

Thank you for purchasing a Fishman FT-5 Clip-On Tuner with 360° display. Your FT-5 provides convenient and highly accurate tuning for guitars, ukuleles, violins, autoharps, and many other stringed instruments. The display can be rotated for easy use and the clip can be attached to headstocks and soundboards for convenient mounting.

## **Controls**

---




## **Specifications**

---

- Scale – Chromatic steps (A4=440Hz)
- Detection range – AO (27.50Hz) > C8 (4186.0Hz)
- Accuracy – +/-1 cent (1/100 of a semitone)
- Included items – 2 X 1.5V lithium battery (LR44)
- Dimensions – 35mm x 42mm x 29mm (1.38" x 1.65" x 1.14")
- Weight – 13.5g (.48oz)

# Battery Installation

---



1. Open the Battery Cover
2. Paying close attention to +/-, insert 2 LR44 batteries (included)
3. Close the Battery Cover and switch on the FT-5
4. If there is no display, double check that the batteries are clean and the +/- orientation is correct
5. When the screen becomes dim or the tuning indicator becomes slow, it's time to change your battery (please dispose of the old battery properly)

# Operation

---

1. Clip your FT-5 to the headstock, soundboard or other convenient vibrating point on your instrument
2. Press and hold the Power button to turn your FT-5 on/off
3. Follow the display indicators to zero-in on your note which will be shown in the center of the display
4. The Up/Down Arrows will turn from Red to Green when you are in tune
5. To save battery life, the display will automatically shut off after 5 minutes if there is no sound/vibration input

## **FCC Compliance Statement**

Model # FT5

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

### **FCC Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## EU Declaration of Conformity CE:

Hereby, Fishman Transducers, Inc. declares that this FT5 Tuner is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU.

### IMPORTANT:

Please remove the plastic battery insulation sheet before using this tuner.

# **FISHMAN**<sup>®</sup>

Fishman FT-5 Clip-On Tuner  
ACC-TUN-FT5

Fishman and Fishman Transducers are trademarks or tradenames of Fishman Transducers Inc. 513-300-292\_r1